

# Instructions Installing Turn Buttons

## Supplies needed:

- ☐ Window Measurement Tracking Sheet
  - ☐ Template and instructions for the type of attachment you plan to use
  - ☐ Scissors for cutting out the template
  - ☐ Masking tape
  - ☐ Glue (included with your shades)
  - ☐ Turn Buttons
  - ☐ Pencil/pen
- 
- ▶ Match your new shades to their windows based on your measurements.
  - ▶ Print and cut out the templates.  
Poke or punch a hole in the red dots, as shown by the green arrows.
  - ▶ Take the top left template and align it with the top left corner of your window, outside the frame. *It's okay if the curve doesn't match, just make sure the "arms" of the template rest against the top and side of your window frame.*
  - ▶ Use masking tape to secure it in place.
  - ▶ Use a pencil/pen to mark in the hole you poked over the red dots.
  - ▶ Remove the template and align the turn button base with your marks. If the holes do not align, make adjustments based on the dot closest to your window.
  - ▶ If you would like, pre-drill the holes using a 1/16" drill bit (*optional*).
  - ▶ Place a dot of glue on the back of the turn button base, about the size of half a pea.
  - ▶ Place the turn button base over your markings and put a screw in one of the holes. Use a Phillips head screwdriver to tighten the screw gently. Do NOT over-tighten!
  - ▶ Wipe up any excess glue with a paper towel. Repeat with the second screw.
  - ▶ To hang your shade, simply place the grommet over the turn button and twist the latch to secure it!





*Need help?* Email [info@roamingshades.com](mailto:info@roamingshades.com).





## Top Left Turn Button Window Template

TOP




BOTTOM

## Bottom Right Turn Button Window Template



# Top Right Turn Button Window Template

TOP



BOTTOM

# Bottom Left Turn Button Window Template

